

## USING YOUR REMOTE WITH YOUR NEW DVR SERVICE

**REW** (Rewind Live TV or previously recorded program)

**PLAY** (Play a recorded program)

**FFWD** (Fast Forward a previously recorded program)

**RECORD** (Record a current program)

**PAUSE** (Pause live TV or a previously recorded program)

**STOP** (Stop recording TV or a previously recorded program)

**REPLAY** (Replay the previous few seconds of a program)

**EXIT** (Exit any on-screen display to return to regular viewing)

**GUIDE** (Access the cable guide)

**INPUT** (Select the video source)



**PPV** (Direct access to pay-per-view programs)

**LIST** (Display a list of programs that you recorded. This will allow you to select one for viewing)

**LIVE TV** (Displays live TV programming once you have rewind live TV this will allow you to catch back up to live TV)

**LAST** (Return to last selected channel)

**PAGE** (Move up or down through menu screens)

**INFO** (Display channel and program information)

**MENU** (Access any on-screen display for the device selected)

**- DAY +** (View the previous or next day's cable guide)

*To record a future program, find the program on the guide press Ok on the remote. Select record option by using arrow keys on the remote. Press OK on the settings you want to use.*



*1. Record this program.*

*2. Create a series recording (record only new, new & repeats)*

*3. Recording Settings (Start on-time, Stop on-time, or you can choose a time to extend past the program end time)*

*When you are ready to watch a recorded program, press the list button.*

# *DVR Remote Guide*

Motorola DRC800

**620.584.2255**

**888.758.8976**

***www.SKTMainstreet.com***